

## NOTES:

- 1. METHOD OF LATERAL INSTALLATION (STANDARD OR SLOPED RISER) TO BE DETERMINED IN THE FIELD BASED ON DEPTH NEEDED FOR SERVICE CONNECTION.
- 2. INSERT A TEE SHALL BE USED IN LIEU OF WYE WHEN CONNECTING TO EXISTING SEWER MAIN.

## STANDARD LATERAL DETAIL

NOT TO SCALE